

**Power**  
Press to turn on.  
Tap the battery icon on  
the screen to turn off or  
put in standby mode

**Microphone**

**Media controls**  
Volume and  
play/pause

**Headset jack**

**Microphone**

**Notification LED**

**Front-facing camera**

**Touch screen**

**Speaker**

**Speaker**

**Touch-sensitive frame**  
Swipe from the frame onto  
the screen to minimize apps,  
show the menu, and more

**BlackBerry PlayBook™**


**BlackBerry**

**Micro-USB port**  
Connect to your charger  
(with the BlackBerry facing up)  
Connect to a computer  
with a micro-USB cable

**Charging contacts**  
Connect BlackBerry  
rapid chargers to the  
charging contacts

**HDMI port**  
Connect to an  
HD display with a  
micro-HDMI cable

**Micro SIM card tray**  
Open to insert and access  
micro SIM card (based on model)



## Help

Your BlackBerry PlayBook tablet comes with complimentary technical support for 90 days from the date of purchase. To register for this support and to view the terms and conditions, visit [www.blackberry.com/playbookgettingstarted](http://www.blackberry.com/playbookgettingstarted).



After you set up your tablet, to see detailed how-to information right on your tablet, open the Help app.



To complete tutorials and to review and change features, open the Setup app.

**Note:** A network connection is required to perform software updates and to set up your BlackBerry ID.

## Gestures



Swipe down to show menus



Swipe up to show the home screen and minimize apps



Swipe from frame to frame to wake up your tablet



Swipe in to show the keyboard

Before using your tablet, read the *Safety and Product Information* booklet provided.

Purchase accessories for your tablet at [www.shopblackberry.com](http://www.shopblackberry.com).

